

Billi Wall Mount Sensor Tap Hands-free Sensor Tap Installation guide



Installation procedure.

1. Determine Component Location Determine the location of each of the

components, taking into account the tube lengths and space available. The installation location should be away from sources of bright light and sunshine. (see Diagram 1)

2. Plan Dispense Position

Determine the position of dispenser mounting hole in ceramic wall. Hole size required is 45mm. (see Diagram 2)

3. Fit Tap Base and Faucet Body

- a) Fit PVC tube inside wall cavity.b) Screw brass nut through wall into
- PVC fixed joint. c) Thread water supply hose and wiring
- loom through brass nut and PVC tube. d) Fit tap body to brass nut and tighten
- grub screws. e) Fit cover over tap body and brass nut. (see Diagram 3)







Appropriate colour coded sticker compliant to local water regulatory requirements must be attached to front of spout to indicate the water temperature dispensed by the tap. (see Diagram 4)



Installation procedure.

4. Mount Control Box

Control box must be fitted no more than 1100mm from tap. Transformer power supply lead is 1300mm long. Attach control box to wall using 4 supplied wall plugs and screws. (see Diagram 5)

5. Control Box Connections

- a) Attach gasket and hose adapter to water outlet.
- b) Fit tap supply hose to hose adapter and secure with spring clamp.
- c) Attach wiring loom to 4 pin electrical socket and finger tighten locking ring.
- d) Attach a 1/2" mains water connection (max 700kpa) to water inlet. (see Diagram 6)

6. Power Supply Connection

Connect small 2 pin transformer plug to 2 pin socket lead on control plug. Plug transformer into standard 240V 10A wall outlet and switch on.

7. Commisioning

- a) Turn water supply on and check for leaks.
- b) Wipe clean sensor window on spout. (see Diagram 7)
- c) Press red 'Distance Detect' button on side of control box. This will allow the unit to adjust to light conditions in the installed location. You may hear the solenoid valve operating during this procedure. (see Diagram 8)
- d) Test operation by placing hands under tap.
 Water should flow within 0.5 seconds of detecting hands. (see Diagram 9)
- e) Move hands away from tap. Water supply should stop within 0.5 seconds. (see Diagram 10)













Troubleshooting.

FAULT	CAUSE	ACTION
No water	– Water supply cut off	– Check water supply
	– Dirt in the filter	 Check filter (located in water inlet fitting)
	– Water pressure too low	– Raise pressure
Water will not turn off	– Sensor window dirty	– Clean sensor window
Too little water flow	 Water supply restricted 	– Check water supply
	– Dirt in the filter	– Check filter
	– Water pressure too low	– Raise pressure
Too much water flow	– Water supply turned on too high	– Adjust supply
	– Water pressure too high	– Adjust pressure
Indicator light not on	– PCB or wiring loom wet	– Dry components

Billi Australia Pty Ltd

42 Lucknow Crescent, Thomastown Victoria 3074 Australia

Telephone +61 3 9469 0400 Facsimile +61 3 9469 0499

www.billi.com.au

Designed and manufactured in Australia.

As Billi Australia Pty Ltd has a policy of continual improvement, all details are subject to change without notice. All goods are sold subject to our published terms and conditions. Billi is a registered trademark. 0618